

Tenorblockflöte in c'
 Tenor recorder in c'
 Flûte à bec Ténor en do'

Mollenhauer-Modell

Helder
 mit H-Klappe
 with B-key
 avec clé de si grave

Barocke Griffweise
 Baroque fingering
 Doigté baroque



The chart displays musical notation on a treble clef staff with notes and their corresponding fingerings on a recorder. The notes are: C4 (whole), D4 (quarter), E4 (quarter), F4 (quarter), G4 (quarter), A4 (quarter), B4 (quarter), C5 (quarter), D5 (quarter), E5 (quarter), F5 (quarter), G5 (quarter), A5 (quarter), B5 (quarter), C6 (quarter). Fingerings are indicated by black dots (closed) and white circles (open) on the recorder's finger holes. The B4 note uses the H-key (B-flat).

- | | | | | | | | |
|--------|-------------|-------------|------------|--------|-------------|--------------------------------|------------------------|
| a) | b) | c) | d) | ○ | ● | ◐ ◑ | ◎ |
| Daumen | linke Hand | rechte Hand | Schallloch | offen | geschlossen | halb- oder teilgedeckt | bei Bedarf geschlossen |
| thumb | left hand | right hand | bell | open | closed | half or partly closed | closed if necessary |
| pouce | main gauche | main droite | pavillon | ouvert | fermé | à demi ou partiellement bouché | fermé au besoin |